

What's if for? ... to make sure the silage inoculant does it's job economically.



The dribble bar fastened above the bale chamber gets it to the right place.

Unlike other systems this one cuts the flow automatically to prevent wasting solution. This applicator stops itself while the bale is being rolled.

The bar rests on the pick up reel and presses the red button as the grass moves through. When it stops the button is released and the flow stops.





Attach the u bolts to the bar in front of the pickup reel.

2 litres of the solution per bale is ideal. There's no chopping or blowing to mix it in, so more is needed to make sure it spreads through well.



The control box has a range from 1.6I per minute to 4I per minute. This means you can adjust the rate to match the thickness of the sward.

These wires should be connected to the short wires on the control box.



The spring loaded joint bends. This means that large clumps of grass can pass through without damaging the switch.

The Servanté Round Bale Applicator Servanté Systems, Morecambe Ville, Star Street, Ulverston, Cumbria LA12 7BY Phone: 01229 583580 Fax: 01229 580599 Email: <u>enquiries@servantesystems.co.uk</u> Website: <u>www.servantesystems.co.uk</u>